

1. R1 Slat pick-up
from disposers

4. R2 Screwing the slat to substructure

2. R1 Cutting on the table saw

3. R1 Positioning the slat on the
assembly frame

5.(optional) R1slat manipulation with
circular saw or milling spindle

